


FIG .01
AIR FILTER



No	Code	Description	Quantity
1	B39A010001	Air filter assy	1
2	B39A 010002	Fill valve	1
3	B39A 010003	Elbow	1
4	B39A 010004	Outlet pipe	1
5	B39A 010005	Vacuum tube	1
6	B39A 010006	Inlet pipe	1
7	B39A 010007	Clip $\Phi 8.5$	4
8	B39A 010008	Clip $\Phi 7.6$	2
9	B39A 010009	Hexagon bolt M6×35	2
10	B39A 010010	Air filter	1

FIG .02


SEAT, LUGGAGE BOX



No	Code	Description	Quantity
1	B39A 020001	Seat	1
2	B39A 020002	Installing plate, seat	1
3	B39A 020003	Pin, M6×65	1
4	B39A 020004	Hexagon nut M6	3
5	B39A 020005	Rear Bracket	1
6	B39A 020006	Inner Hexagon bolt M8×20	4
7	B39A 020007	Luggage box	1
8	B39A 020008	Gaskets M6	2
9	B39A 020009	Acorn Nut M6	2
10	B39A 020010	Hexagon bolt M6×16	2
11	B39A 020011	Inner cover,luggage box	1
12	B39A 020012	Tapping screw ST4.2×12	1
13	B39A 020013	Front cover, luggage box	1
14	B39A 020014	Clip 4.2	4
15	B39A 020015	Tapping screw ST4.8×16	4


FIG .03

SPEEDOMETER, HEADLIGHT ASSY



No	Code	Description	Quantity
1	B39A 030001	Speedometer assy	4
2	B39A 030002	Speedometer cover	1
3	B39A 030003	Tapping screw ST4.2×12	4
4	B39A 030004	Pan bolt M6×16	1
5	B39A 030005	Headlight assy.	1
6	B39A 030006	Windscreen assy	1
7	B39A 030007	Clip 4.2	2
8	B39A 030008	Tapping screw ST4.8×16	2
9	B39A 030009	Tapping screw ST4.2×12	2

FIG .04
Front cover ASSY.




No	Code	Description	Quantity)
1	B39A 040001	Front cover around	1	
2	B39A 040002	L.turning light	1	
3	B39A 040003	R.turning light	1	
4	B39A 040004	Front cover deck	1	
5	B39A 040005	Front cover	1	
6	B39A 040006	Clip 4.2	6	
7	B39A 040007	Tapping screw ST4.8×16	8	
8	B39A 040008	Tapping screw ST4.2×12	18	
9	B39A 040009	Bolt,hexagon M6×16	1	

**FIG .05
FARME**



No	Code	Description	Quantity
1	B39A 050001	Farme	1
2	B39A 050002	Main stand	1
3	B39A 050003	Buffer rubber, Main stand	1
4	B39A 050004	Main stand, Axis Pin 8*170	1
5	B39A 050005	Pin 2.3×27	1
6	B39A 050006	Spring, main stand	1
7	B39A 050007	Side stand	1
8	B39A 050008	Inner Hexagon bolt M8×20+shaft positionΦ13	1
9	B39A 050009	Spring, side stand	1
10	B39A 050010	Hanger	1
11	B39A 050011	Buffer rubber, hanger	1
12	B39A 050012	Hexagon bolt M10×1.25×40	2
13	B39A 050013	Main stand, Axis Pin M10×1.25×225	1
14	B39A 050014	Locked nut M10*1.25	1
15	B39A 050015	Seat lock bracket	1
16	B39A 050016	Hexagon bolt M6×12	2
17	B39A 050017	Bracket, front cover	1
18	B39A 050018	Hexagon bolt M6×55	2
19	B39A 050019	Hexagon nut M6	2


**FIG .06
ENGINE ASSY**



No	Code	Description	Quantity
1	B39A 060001	Engine139QMB	1
2	B39A 060002	Carburetor PD18J	1
3	B39A 060003	Connecting plate	1
4	B39A 060004	Bush,Rear wheel	1
5	B39A 060005	Bush,Rear wheel	1
6	B39A 060006	Nut M16*1.5	1
7	B39A 060007	Bolt,hexagon M8×55	1
8	B39A 060008	Bolt,hexagon M8×65	1
9	B39A 060009	Rear absorber(F.R)	1
10	B39A 060010	Bolt,hexagon M10×1.25×40	2
11	B39A 060011	Nut M10×1.25	1
12	B39A 060012	Muffler assy.	1
13	B39A 060013	Seal ring	1
14	B39A 060014	Acorn nut M6	2


FIG .07

PLASTIC PARTS、TAILLIGHT ASSY




No	Code	Description	Quantity
1	B39A 070001	Rear L Turning light	1
2	B39A 070002	Rear R Turning light	1
3	B39A 070003	L.decorative plate	1
4	B39A 070004	R.decorative plate	1
5	B39A 070005	L.small plate,decorative plate	1
6	B39A 070006	R. small plate,decorative plate	1
7	B39A 070007	Rear.decorative plate	1
8	B39A 070008	Taillight assy.	1
9	B39A 070009	Tapping screw ST4.2×12	14
10	B39A 070010	Tapping screw ST4.8×16	2
11	B39A 070011	Clip 4.2	2

FIG .08
FRAME FENDER



No	Code	Description		Quantity	
1	B39A 080001	Frame fender		1	
2	B39A 080002	Hexagon bolt M6x12		4	


FIG .9
STEERING HANDLE



No	Code	Description	Quantity
1	B39A 090001	Steering handle	1
2	B39A 090002	Hexagon bolt M10×1.25×50	1
3	B39A 090003	Washer,steering handle	1
4	B39A 090004	Hexagon nut M10×1.25	1
5	B39A 090005	L. switch	
6	B39A 090006	R. switch	
7	B39A 090007	Rear mirror	1
8	B39A 090008	R, Grip	1
9	B39A 090009	L, Grip	1

FIG .10

TOOL BOX, FOOTBOARD




No	Code	Description	Quantity
1	B39A 100001	Tool box	1
2	B39A 100002	Inner cover,Tool box	1
3	B39A 100003	VIN plate	1
4	B39A 100004	Footboard	1
5	B39A 100005	Battery cover	1
6	B39A 100006	R. side plate, footboard	1
7	B39A 100007	L. side plate,footboard	1
8	B39A 100008	Footboard rubber	1
9	B39A 100009	Hexagon nut M6×16	1
10	B39A 100010	Tapping screw ST4.2×12	16
11	B39A 100011	Hexagon bolt M6×12	4
12	B39A 100012	Clip 4.2	6
13	B39A 100013	Tapping screw ST4.8×16	6

FIG .11
FUEL TANK



No	Code	Description	Quantity
1	B39A 110001	Fuel tank	1
2	B39A 110002	Cap,Fuel tank	1
3	B39A 110003	Fuel sensor	1
4	B39A 110004	Washer,sealing	1
5	B39A 110005	Fixing Plate, Sensor	1
6	B39A 110006	Fuel Switch	1
7	B39A 110007	Clip springΦ8.5	4
8	B39A 110008	Clip springΦ7.6	2
9	B39A 110009	Vacuum tube Φ3.8×Φ7.6×550	1
10	B39A 110010	Pipe Φ4.7×Φ8.5×250	1
11	B39A 110011	Pipe Φ4.7×Φ8.5×220	1
12	B39A 110012	Oil filter Cover	1
13	B39A 110013	Oil filter	1
14	B39A 110014	Hexagon bolt M6×12	4
15	B39A 110015	Spring A	1
16	B39A 110016	Spring B	1
17	B39A 110017	Spring C	1

FIG .12
SET LOCK ASSY




No	Code	Description	Quantity
1	B39A 120001	Ignition lock	1
2	B39A 120002	Cover, Ignition lock	1
3	B39A 120003	Key	2
4	B39A 120004	Hexagon bolt M8x25	2
5	B39A 120005	Seat lock cable	1
6	B39A 120006	Pan bolt M6x10	1

**FIG .13
REAR WHEEL**




No	Code	Description	Quantity
1	B39A 130001	Rear wheel	1
2	B39A 130002	Air valve	1
3	B39A 130003	Tyre 3.50-10	1
4	B39A 130004	Brake shoe	1
5	B39A 130005	Rear brake cable	1
6	B39A 130006	Rear brake Camshaft	1
7	B39A 130007	Restoration spring	1
8	B39A 130008	Rocker, camshaft	1
9	B39A 130009	Hexagon bolt M6x35	1

FIG .14
ELECTRIC



No	Code	Description	Quantity
1	B39A 140001	Main cable	1
2	B39A 140002	Electric horn	1
3	B39A 140003	Rectifier	1
4	B39A 140004	Bolt,hexagon M6×16	2
5	B39A 140005	Bolt,hexagon M6×12	1
6	B39A 140006	cincture	5
7	B39A 140007	L. switch assy	1
8	B39A 140008	R. switch assy	1
9	B39A 140009	Bolt,M5×10	1
10	B39A 140010	Relay	1
11	B39A 140011	Throttle cable	1
12	B39A 140012	Speedometer cable	1
13	B39A 140013	Flasher	1
14	B39A 140014	Power wire	1
15	B39A 140015	Grounding wire	1
16	B39A 140016	Pan bolt,M6×20	1
17	B39A 140017	High pressure package	1
18	B39A 140018	CDI	1

**FIG .15
REAR FENDER**



No	Code	Description	Quantity
1	B39A 150001	Rear fender	1
2	B39A 150002	License light	1
3	B39A 150003	Reflector	1
4	B39A 150004	Licens Bracke	1
5	B39A 150005	Side reflecter	2
6	B39A 150006	Fender,rear wheel	1
7	B39A 150007	Fender Bracket,rear wheel	1
8	B39A 150008	Tapping screw ST4.2×12	2
9	B39A 150009	Tapping screw ST4.2×12	6
10	B39A 150010	Hexagon nut M6	2
11	B39A 150011	Hexagon bolt M6×16	2

FIG .16
FRONT ABSORBER ASSY.



No	Code	Description	Quantity
1	B39A 160001	Steering stem	1
2	B39A 160002	R.front absorber	1
3	B39A 160003	L.front absorber	1
4	B39A 160004	Nut M25×1	1
5	B39A 160005	Race,steering top ball	1
6	B39A 160006	Uper balls, bearing	1
7	B39A 160007	Uper balls, bearing race	1
8	B39A 160008	Under balls, bearing race	1
9	B39A 160009	Race,steering bottom ball	1
10	B39A 160010	Under balls. Bearing	1
11	B39A 160011	Fr.rim	1
12	B39A 160012	Disc brake plate	1
13	B39A 160013	Inner hexagon bolt M8×20+shaft Φ9.7×4.5	1
14	B39A 160014	Tyre 3.50-10	1
15	B39A 160015	Counter	1
16	B39A 160016	Front.disc brake assy	1

FIG .16
FRONT ABSORBER ASSY.



No	Code	Description	Quantity
17	B39A 160017	Front fender	1
18	B39A 160018	Front fender small cover	1
19	B39A 160019	Speedometer cable bracket	1
20	B39A 160020	Disc brake pipe bracket	1
21	B39A 160021	Hexagon bolt M10×35	4
22	B39A 160022	Hexagon bolt M6×12	5
23	B39A 160023	Shaft,FR.wheel	1
24	B39A 160024	FR.axlle M12×1.25×220	1
25	B39A 160025	Hexagon locked nut M12×1.25	1
26	B39A 160026	Hexagon bolt M10×30	2
27	B39A 160027	Clip 4.2	1
28	B39A 160028	Tapping screw ST4.8×16	1
29	B39A 160029	Air valve	1

**FIG .17
BATTERY**



No	Code	Description		Quantity	
1	B39A 170001	Battery		1	
2	B39A 170002	Electrolyte		1	

FIG .18
TOOL



No	Code	Description	Quantity
1	B39A 180001	Tool set	1
2	B39A 180002	Sleeve,spark plug	1
3	B39A 180003	Screwdriver grip	1
4	B39A 180004	Spanner 8×10	1
5	B39A 180005	Spanner 14×17	1
6	B39A 180006	Screwdriver	1
7	B39A 180007	Tool bag	1
8	B39A 180008	Spanner 10×12	1
9	B39A 180009	Inner hexagon spanner	1