



F-1 (FRAME ASSY):




No	Part No	Description	Qty	REMARKS
1	010001	Frame	1	
2	010002	Under balls. Bearing	1	
3	010003	Upper balls, bearing race	1	
4	010004	Side stand	1	
5	010005	Bolt,side stand	1	
6	010006	Spring, side stand hanger	1	
7	010007	Spring,side stand	1	
8	010008	L.footrest cover	1	
9	010009	L. footrest	1	
10	010010	Bolt,flange M6×40	2	
11	010011	Nut, Flange M6	2	
12	010012	Right .footsie cover	1	
13	010013	Right .footrest	1	
14	010014	Hanger	1	
15	010015	Cushion Bush of hanger	2	

F-1 (FRAME ASSY):




No	Part No	Description	Qty	REMARKS
16	010016	Rubber of hanger	2	
17	010017	Bolt,flange M10×55	2	
18	010018	Bush of Hanger	1	
19	010019	Engine Hanger axes M10×220	1	
20	010020	Lock Nut, Flange M10	1	
21	010021	Main stand	1	
22	010022	Rubber,main stand	1	
23	010023	Rubber,main stand of Bolt M6×30	1	
24	010024	Bolt,flange M8×25	2	
25	010025	Bush	2	
26	010026	Sping,mainstand	1	
27	010027	Seat lock	1	
28	010028	Cable, seat lock	1	

F-2 (FRONT FORK ASSY):




No	Part No	Description	Qty	REMARKS
1	020001	Front fork	1	
2	020002	Under balls, bearing race	1	
3	020003	Race, steering bottom ball	1	
4	020004	Race, steering top ball	1	
5	020005	Under balls, bearing race	1	
6	020006	Lock nut	1	
7	020007	Left rocker	1	
8	020008	Ring,dustproof A	4	
9	020009	Ring,dustproof B	6	
10	020010	Ring,dustproof C	3	
11	020011	Lock Nut, Flange M10	2	
12	020012	Right rocker	1	
13	020013	Front brake rocker	1	
14	020014	Below pumb, axes	1	

F-2 FRONT FORK ASSY):



No	Part No	Description	Qty	REMARKS
15	020015	Front brake assy.	1	
16	020016	Upper pump, front disk brake	1	
17	020017	Bolt,flange M6×25	2	
18	020018	Front brake lever	1	
19	020019	Front brake lever, bolt	1	
20	020020	Nut, Flange M6	1	
21	020021	Bolt, hexagon M8×35	1	
22	020022	Front brake line	1	
23	020023	Counter17 : 8	1	
24	020024	Bolt	1	
25	020025	Speedometer cable	1	
26	020026	Front fender	1	
27	020027	Front fender ornament	1	
28	020028	Screw,tapping ST4.2×16	4	

F-2 (FRONT FORK ASSY):




No	Part No	Description	Qty	REMARKS
29	020029	Bolt,flange M6×12	1	
30	020030	Front shock absorber	2	
31	020031	Bolt,flange M8×38	2	
32	020032	Nut, Flange M8	2	
33	020033	Front rim MT2.50×J12	1	
34	020034	Valve,tyre	2	
35	020035	Disc brake	2	
36	020036	Installing screw,brake disc	3	
37	020037	Tyre 120/70-12	1	
38	020038	Front-wheel and axle M12×242	1	
39	020039	Bush 44mm	1	
40	020040	Lock Nut, M12	1	
41	020041	Left rocker cover	1	
42	020042	Right rocker cover	1	
43	020043	Left front fork cover	1	
44	020044	Right front fork cover	1	

F-3 (ENGINE ASSY):



No	Part No	Description	Qty	REMARKS
1	030001	Engine	1	
2	030002	Carburetor	1	
3	030003	Rear rim MT2.50×J12	1	
4	030004	Air valve	1	
5	030005	Rear tyre 120/70-12	1	
6	030006	Camshaft	1	
7	030007	Restoration Spring	1	
8	030008	Cam, rear brake	1	
9	030009	Bolt, flange M6×30	2	
10	030010	Spring	2	
11	030011	Brake shoe	2	
12	030012	Connecting plate	1	

F-3 (ENGINE ASSY):




No	Part No	Description	Qty	REMARKS
13	030013	Spacer 29.5mm	1	
14	030014	Spacer 6mm	1	
15	030015	Lock Nut, Flange M16	1	
16	030016	Bolt, flange M8×70	1	
17	030017	Bolt, flange M8×35	1	
18	030018	Rear shock absorber	2	
19	030019	Bolt, flange M10×50	2	
20	030020	Bolt, flange M10×40	2	
21	030021	Lock Nut, Flange M16	2	
22	030022	Muffler	1	
23	030023	Ring, sealing	1	
24	030024	Nut, acorn M6×32	2	

F-3 (ENGINE ASSY):




No	Part No	Description	Qty	REMARKS
25	030025	Air-filter Clip	1	
26	030026	Air-filter	1	
27	030027	Rear wheel fender	1	
28	030028	Left bracket	1	
29	030029	Bolt,flange M6×15	1	
30	030030	Clip Nut M6	1	
31	030031	Right bracket	1	
32	030032	Bolt,flange M6×20	1	
33	030033	Nut flange M6	1	
34	030034	Right bracket	1	

F-4 (STEERING HANDLE ASSY):




No	Part No	Description	Qty	REMARKS
1	040001	Holder, steering handle	1	
2	040002	Bracket,steering handle	2	
3	040003	Steering handle	1	
4	040004	Plate, steering handle	1	
5	040005	Cover, steering handle	1	
6	040006	Brake handle	1	
7	040007	Front brake assy.	1	
8	040008	Switch, left	1	
9	040009	Switch, right	1	
10	040010	Grip, Left handle	1	
11	040011	Throttle grip	1	
12	040012	Rear brake cable	1	
13	040013	Throttle cable	1	

F-5 (FUEL TANK ASSY):



No	Part No	Description	Qty	REMARKS
1	050001	Tank, fuel	1	
2	050002	Fuel tank cap	1	
3	050003	Sensor, fuel	1	
4	050004	Washer, sealing	1	
5	050005	Press borad of Sensor, fuel	1	
6	050006	Bolt, flange M6x12	1	
7	050007	Pump vacuum	1	
8	050008	Filter	1	
9	050009	Cover fuel sensor	2	
10	050010	Pipe	2	
11	050011	Pipe	2	
12	050012	Pipe	1	

F-5 (FUEL TANK ASSY):




No	Part No	Description	Qty	REMARKS
13	050013	Tube,vacuum	1	
14	050014	Clip □	7	
15	050015	Clip II	3	
16	050016	Bolt,flange M6×16	2	
17	050017	cut-off valve	1	
18	050018	Pipe 350mm	1	
19	050019	Pipe 680mm	1	
20	050020	Tube,vacuum 350mm	1	
21	050021	Big clip	1	

F-7 (FRONT COVER):




No	Part No	Description	Qty	REMARKS
1	070001	Front cover	1	
2	070002	Turning light ,L	1	
3	070003	Turning light, R	1	
4	070004	Screw, tapping ST4.2×16	10	
5	070005	Screw, pan M6×12	2	
6	070006	Front cover	1	
7	070007	Front grid	1	
8	070008	Front small cover	1	

F-8 (LUGGAGE BOX ASSY) :




No	Part No	Description	Qty	REMARKS
1	080001	Tool chest	1	
2	080002	Ignition lock cap	1	
3	080003	Cover tool chest	1	
4	080004	Lock	2	
5	080005	Clip	2	
6	080006	Key	2	
7	080007	Press	4	
8	080008	Screw, tapping ST4.2×16	31	
9	080009	Bolt, hexagon M6×12	1	
10	080010	Footboard	1	
11	080011	Plastic cover tank	1	
12	080012	Clip	4	

F-8 (LUGGAGE BOX ASSY):




No	Part No	Description	Qty	REMARKS
13	080013	Bolt, washer M6×16	4	
14	080014	VIN number cover	1	
15	080015	L. Luggage box	1	
16	080016	L. decoration, Luggage box	1	
17	080017	Small cover, L Luggage box	1	
18	080018	R. Luggage box	1	
19	080019	R. decoration, Luggage box	1	
20	080020	Small cover, R. Luggage box	1	

F-9 (FENDER ASSY):



No	Part No	Description	Qty	REMARKS
1	090001	Rear fender	1	
2	090002	Reflector	1	
3	090003	Nut, hexagon M6	5	
4	090004	Rear fender stand	1	
5	090005	Bolt, hexagon M6x12	8	
6	090006	Bolt, washer M6x16	1	
7	090007	Bottom board	1	
8	090008	Footplate ,left regula	1	
9	090009	Footplate ,right regula	1	
10	090010	Bolt, hexagon M6x12	4	
11	090011	Clip	10	
12	090012	Screw, tapping ST4.2x16	10	
13	090013	license bracket	1	
14	090014	Side reflector	2	

F-10 (REAR PLASTIC PARTS ASSY) :




No	Part No	Description	Qty	
1	100001	L. decorative plate	1	
2	100002	Seat lock	1	
3	100003	Bracket, seat lock	1	
4	100004	Clip	1	
5	100005	Left regula	1	
6	100006	Clip	4	
7	100007	Screw, tapping ST4.2x16	18	
8	100008	Bolt, flange M6x12	2	
9	100009	R, protecting plate	1	
10	100010	Right regula	1	
11	100011	Empennage	1	
12	100012	Taillight	1	
13	100013	Nut, hexagon M6	3	

F-11 (SEAT ASSY):



No	Part No	Description	Qty	REMARKS
1	110001	Seat	1	
2	110002	Gemel,seat	1	
3	110003	Bolt,step M6	1	
4	110004	Nut,flange M6	3	
5	110005	Luggage box	1	
6	110006	Bolt,flange M6×12	2	
7	110007	Screw,tapping ST4.2×16	5	
8	110008	Cover,luggage box	1	
9	110009	Cover Battery	1	

F-12 (ELECTRIC APPLIANCE ASSY):



No	Part No	Description	Qty	REMARKS
1	120001	Cable,main	1	
2	120002	Lock,ignition switch	1	
3	120003	Bolt,flange M6×16	4	
4	120004	Rectifier	1	
5	120005	Bolt,flange M6×12	4	
6	120006	CDI	1	
7	120007	Cover CDI	1	
8	120008	Starting relay	1	
9	120009	Cover starting relay	1	
10	120010	Negative wire	1	
11	120011	Positive wire	1	
12	120012	Grounding wire	1	
13	120013	Coil,ignition	1	
14	120014	Electric horn	1	
15	120015	Flasher	1	
16	120016	Flasher cover	1	
17	120017	Resistance	1	

F-15 (TOOL):



No	Part No	Description	Qty
1	150001	Tool bag	1
2	150002	Grip, screwdriver	1
3	150003	Screwdriver	1
4	150004	Wrench, spark plug	1
5	150005	Spanner, inner hex	1
6	150006	Spanner, 10×12	1
7	150007	Spanner, 8×10	1
8	150008	Spanner, 14×17	1